

QUICK LINK FITTING INSTRUCTIONS

1. Push two single beds together, side by side and lay the poly cotton quilted pad across the gap between the two mattresses.
2. Feed one end of the belt through the loop of the poly cotton quilted pad at the top of the mattresses, and place the adjustable belt around the side of one of the mattresses.
3. Take the other end of the belt around the other mattress and through the loop on the poly cotton quilted pad at the bottom of the mattresses.
4. Bring the two ends of the belt together along one side of the mattresses, snap the buckle shut and pull the belt tight so the beds are held firmly together.
5. Place a Super King Mattress Protector or blanket over the Quick Link Pad and then make the bed as usual.

